FIG. 1

FIG. 2

bus ID (10bit)		Node ID (6bit)		Offset Hi (20bit)		Offset Lo (28bit)	
bus# 0		node# 0		Initial memory space		CSR Architecture	000h
bus# 1		node# 1				Serial Bus	200h
							400h
						Config ROM	
							800h
				-------		Initial units spac	
							900h
						SCRs	A00h
bus# 1022		node# 62					
			FFFFFh	private space			
bus# 1023 (local bus)		node# 63 (broadcast)		Initial register space			FFF FFFFh

FIG. 3

| Offset	Designation	Function
000h	STATE_CLEAR	State and control data
004h	STATE_SET	Set state_clear bit
008h	NODE_IDs	Indicate node ID of 16 bits
00Ch	RESET_START	Start command reset
018h-01Ch	SPLIT_TIMEOUT	Specify maximum time of split
200h	CYCLE_TIME	Cycle time
210h	BUSY_TIMEOUT	Specify limit on retry
21Ch	BUS_MANAGER	Indicate ID of bus manager
220h	BANDWIDTH_AVAILABLE	Indicate band that can be assigned to isochronous communication
224h-228h	CHANNELS_AVAILABLE	Indicate the state where the channels are used

FIG. 4

info_length	crc_length	rom_crc_value

Info_length

bus_info_block
root_directory
unit_directories
root & unit leaves

FIG. 6

900h	Output Master Plug Register
904h	Output Plug Control Register #0
	Output Plug Control Register #1
	⋮
97Ch	Output Plug Control Register #30
980h	Input Master Plug Register
984h	Input Plug Control Register #0
988h	Input Plug Control Register #1
	⋮
9FCh	Input Plug Control Register #30

FIG. 5

	crc_length	rom_crc_value
04h		

Bus_info_block

"1394"
rmc	cmc	isc	bmc	reserved	cyc_clk_acc	max_rec	reserved
Company_ID							Chip_ID_hi
Chip_ID_lo

400h
404h
408h
40Ch
410h

Root_directory

root_length	CRC
03h	module_vendor_id
0Ch	node_capabilities
8Dh	node_unique_id offset
D1h	unit_directory offset
	Optional.

414h
418h
41Ch
420h
424h
428h

unit_directory

unit_directory_length	CRC
12h	unit_spec_id
13h	unit_sw_version
	Optional.

FIG. 7A

oMPR

data rate capability	Broadcast channel base	non-persistent extension field	persistent extension field	reserved	number of output plugs
2	6	8	8	3	5 (bit)

FIG. 7B

oPCR [n]

on-line	Broadcast connection counter	point-to-point connection counter	reserved	channel number	reserved	data rate	overhead ID	payload
1	1	6	2	6	2	2	4	10 (bit)

FIG. 7C

iMPR

data rate capability	reserved	non-persistent extension field	persistent extension field	reserved	number of input plugs
2	6	8	8	3	5 (bit)

FIG. 7D

iPCR [n]

on-line	Broadcast connection counter	point-to-point connection counter	reserved	channel number	reserved
1	1	6	2	6	16 (bit)

FIG. 8

FIG. 9

FIG. 10

The General Subunit Identifier Descriptor	
address	contents
00 00$_{16}$	descriptor__length
00 01$_{16}$	
00 02$_{16}$	generation__ID
00 03$_{16}$	size__of__list__ID
00 04$_{16}$	size__of__object__ID
00 05$_{16}$	size__of__object__position
00 06$_{16}$	number__of__root__object__lists(n)
00 07$_{16}$	
00 08$_{16}$ ⋮	root__object__list__id__0
⋮	⋮
⋮	root__object__list__id__n-1
⋮	subunit__dependent__length
⋮	subunit__dependent__information
⋮	manufacturer__dependent__length
⋮	manufacturer__dependent__ information

FIG. 11

generation_ID values	
generation_ID	meaning
00_{16}	Data structures and command sets as specified in the AV/C General Specification, version 3.0
all others	reserved for future specification

FIG. 12

List ID Value Assignment Ranges	
range of values	list definition
0000_{16}–$0FFF_{16}$	reserved
1000_{16}–$3FFF_{16}$	subunit-type dependent
4000_{16}–$FFFF_{16}$	reserved
$1\ 000_{16}$ –max list ID value	subunit-type dependent

FIG. 13

Command
1394 TA Spec

AV/C Digital Interface Command Set

86

Digital Interface
IEC 61883 CDV

CSRs

Configuration ROM

ISO/IEC 13213

Serial Bus Management

84

Function Control Protocol

85

83

Transaction Layer

82

Link Layer

81

Physical Layer

IEEE 1394-1995 Std

FIG. 14

Controller
(Transaction Layer)

Target
(Transaction Layer)

Transaction Request

Command

Write request packet

Transaction indication

Ack

Response

Transaction Request

Write request packet

Transaction indication

Ack

FIG. 15

IEEE 1394 bus

Node A

Initial register space

Register address	
0000 B000h	Command register (512bytes) — 91
0000 D000h	Response register (512bytes) — 92

NodeB

Initial register space

Register address	
0000 B000h	Command register (512bytes) — 93
0000 D000h	Response register (512bytes) — 94

FIG. 16

Asynchronous Packet (Write Request for Data Block)

transmitted
first

destination_ID		ti	rt	tcode	pri	← packet header
source_ID		destination_offset=				
FCP_RESPONSE/FCP_COMMAND register						
data_length		extended_tcode				
header_CRC						
CTS=0000	ctype/response	subunit type	id	opcode	operand	← data block
Additional operands (if necessary)						
padding (if necessary)						
data_CRC						

— 1 quadlet=32bits — transmitted first

FIG. 17A

ctype/response

Command	0000	CONTROL
	0001	STATUS
	0010	SPECIFIC INQUIRY
	0011	NOTIFY
	0100	GENERAL INQUIRY
	0101 ~ 0111	(reserved for future spcification)
Response	1000	NOT IMPLEMENTED
	1001	ACCEPTED
	1010	REJECTED
	1011	IN TRANSITION
	1100	IMPLEMENTED/STABLE
	1101	CHANGED
	1110	(reserved for future specification)
	1111	INTERIM

FIG. 17B

subunit_type

00000 ~ 00000	Video monitor (reserved) Disc recorder/Player
00100	Tape recorder/Player
00101	Tuner
00111	Video Camera
~	(reserved)
11100	Vendor unique
11101	(reserved)
11110	Subunit type extended to next byte
11111	Unit*

FIG. 17C

opcode:Operation Code

00h	VENDOR-DEPENDENT
50h	SEARCH MODE
51h	TIMECODE
52h	ATN
60h	OPEN MIC
61h	READ MIC
62h	WRITE MIC
C1h	LOAD MEDIUM
C2h	RECORD
C3h	PLAY
C4h	WIND
~	~

FIG. 18A

AV/C control	control	tape recorder /player	when ID 0	PLAY	FORWARD
CTS= 0000	ctype= 0000	subunit type=00100	id=000	opcode=C3h	operand= 75h

FIG. 18B

AV/C accepted		tape recorder /player	when ID 0	PLAY	FORWARD
CTS= 0000	response =1001	subunit type=00100	id=000	opcode=C3h	operand= 75h

FIG. 19

FIG. 20

Error check —— S1

Is there error change ? —— S2

NO

YES

Is there error ? —— S3

NO

YES

Request display module to display error display information —— S4

FIG. 21

```
                    ┌─────────────────┐
                    │   Error check   │───S11
                    └─────────────────┘
                             │
                             ▼
                    ┌─────────────────┐
                    │   Clear error   │───S12
                    │     display     │
                    │   information   │
                    └─────────────────┘
                             │            S13
                             ▼
                      ╱───────────╲         YES    ┌──────────────────┐
                     ╱   Has bus    ╲──────────────│ Set error display│──S14
                     ╲ reset occurred╱             │   information     │
                      ╲     ?       ╱              │  (bus reset       │
                       ╲───────────╱               │   occurred)       │
                            │ NO                    └──────────────────┘
                            │         S15
                            ▼
                     ╱─────────────╲        YES     ┌──────────────────┐
                    ╱   Has bus     ╲───────────────│ Set error display│
                    │ state become loop             │   information     │
                    ╲ state or non-loop╱            │  (loop state      │
                     ╲   state ?     ╱              │   change)         │
                      ╲─────────────╱               └──────────────────┘
                            │ NO   S17                        │ S16
                            ▼
          NO         ╱───────────╲         YES
       ┌────────────╱     Is       ╲───────────┐
       │            ╲ there connection╱        │
       │             ╲     ?       ╱           │
       ▼              ╲───────────╱            ▼
┌──────────────┐                        ┌──────────────┐
│ Error check in│──S18                  │ Error check in│──S21
│ the case where│                       │ the case where│
│ there is no   │                       │ there is      │
│ connection    │                       │ connection    │
└──────────────┘                        └──────────────┘
       │         S19                           │        S22
       ▼                                        ▼
 ╱───────────╲                           ╱───────────╲
╱  Is there    ╲  NO              YES    ╱  Is there    ╲  NO
╲   error ?   ╱─────┐          ┌────────╲   error ?   ╱─────┐
 ╲───────────╱      │          │         ╲───────────╱      │
      │ YES         │          │              │ YES         │
      ▼             │          │              ▼             │
┌──────────────┐    │          │       ┌──────────────┐     │
│ Set error     │   │          │       │ Set error     │    │
│ display       │   │          │       │ display       │    │
│ information    │──S20         │       │ information    │──S21
│ (reason why   │   │          │       │ (such as       │    │
│ there is no   │   │          │       │ signal error)  │    │
│ connection)   │   │          │       └──────────────┘     │
└──────────────┘    │          │              │             │
         │          │          │              │             │
```

Error display
information ─── S24

FIG. 22

```
        ┌─────────────────────┐
        │ Error check in the  │  S31
        │ case where there is │
        │ no connection       │
        └──────────┬──────────┘
                   │
                   ▼
              ╱─────────╲                    ┌──────────────────────┐
         S32 ╱  Cannot   ╲      YES           │ Set error display    │  S33
            ╱ connection be╲────────────────▶ │ Information (connection│
            ╲ established ? ╱                  │ cannot be established)│
             ╲────────────╱                    └──────────────────────┘
                   │ NO
                   ▼
              ╱─────────╲                    ┌──────────────────────┐
         S34 ╱  Cannot   ╲      YES           │ Set error display    │  S35
            ╱ band be     ╲────────────────▶ │ Information (band cannot│
            ╲ obtained ?   ╱                  │ be obtained)          │
             ╲────────────╱                    └──────────────────────┘
                   │ NO
                   ▼
              ╱─────────╲                    ┌──────────────────────┐
         S36 ╱  Cannot   ╲      YES           │ Set error display    │  S37
            ╱ channel be  ╲────────────────▶ │ Information (channel  │
            ╲ acquired ?   ╱                  │ cannot be obtained)   │
             ╲────────────╱                    └──────────────────────┘
                   │ NO
                   ▼
```

FIG. 23

～S41

```
┌─────────────────────┐
│ Error check in the  │
│ case where there    │
│ is connection       │
└─────────────────────┘
          │
          ▼
        S42                                          S43
     ◇─────────◇                            ┌──────────────────┐
    ╱           ╲         YES               │ Set error display│
   ◇ Isn't there ◇ ────────────────────────▶│ information       │──┐
    ╲  signal ?  ╱                          │ (no signal)      │  │
     ◇─────────◇                            └──────────────────┘  │
          │ NO                                                     │
          ▼                                                        │
        S44                                          S45           │
     ◇─────────◇                            ┌──────────────────┐  │
    ╱  Is ISO   ╲        YES                │ Set error display│  │
   ◇ signal empty◇ ──────────────────────── │ information       │─▶│
    ╲packet ?    ╱                          │ (empty)          │  │
     ◇─────────◇                            └──────────────────┘  │
          │ NO                                                     │
          ▼                                                        │
        S46                                          S47           │
     ◇─────────◇                            ┌──────────────────┐  │
    ╱  Is ISO   ╲        YES                │ Set error display│  │
   ◇ signal empty◇ ──────────────────────── │ information       │─▶│
    ╲ packet ?   ╱                          │ (not locked)     │  │
     ◇─────────◇                            └──────────────────┘  │
          │ NO                                                     │
          ▼                                                        │
        S48                                          S49           │
     ◇─────────◇                            ┌──────────────────┐  │
    ╱   Isn't   ╲        YES                │ Set error display│  │
   ◇  sampling   ◇ ───────────────────────  │ information       │  │
    ╲ frequency  ╱                          │ (frequency        │─▶│
     ╲suitable ?╱                           │ noncoincide)     │  │
      ◇───────◇                             └──────────────────┘  │
          │ NO                                                     │
          ▼                                                        │
        S50                                          S51           │
     ◇─────────◇                            ┌──────────────────┐  │
    ╱   Isn't   ╲        YES                │ Set error display│  │
   ◇signal linear◇ ──────────────────────── │ information       │─▶│
    ╲  PCM ?     ╱                          │ (nonlinear PCM)  │  │
     ◇─────────◇                            └──────────────────┘  │
          │ NO                                                     │
          ▼──────────────────────────────────────────────────────┘
          │
          ▼
```

FIG. 24

Error code number (example) 61	Display message 62	
C78:11 (At the time of device selection)	The selected is conduction 63 Lincs and it cannot code with more Lincs	12 Connection failure of output plug of opposite device side
C78:12 (TUNER, ANALOG)	STR has 63 formed Links and it cannot have more Links	31 Connection failure of its own input
C78:22.22	The case where a different format (signal where cannot be reproduced) it detected	22 The format is not IEC958 format
C78:22.23		23 Discrepancy between N bits (asynchronous) and rate control protocol
C78:22.25		25 The sampling frequency is not suitable
C78:22.26		26 The signal is not linear PCM
C78:31	The case where the signal clock is out of standard values and the PLL lock is not established	24 The signal is unlocked
C78:04	The case where there are not input signals at all during selection of a connection device	21 There are no signal
C78:15.13	Since bus is full of signals output or input cannot be conducted	13 Band is deficient at the time of input
C78:15.14		14 Channel is fully occupied time of output
C78:15.15		15 Band is deficient at the time of output
C78:15.33		33 Channel is fully occupied time of output
C78:03	Loop has been formed by cable connection	
C78:00	Bus reset has occurred (for example in the case where new device is connected)	
C60:01	Temperature within the device is rising	
C60:08	Speaker terminal is short-circuited	
C60:13	Selected device is not connected	

FIG. 25

71

POWER

72

73

There is a loop in
cable connection

Detail   Reinspec-
          tion

74   75

TUNER TV CD MD AUX

VOLUME

76

Connection cannot made in a loop
form disconnect cable one place
somewhere

FIG. 26

FIG. 27